

# ADD TO YOUR SWPPP AS A BETTER **ALTERNATIVE**

# REUSABLE SEDIMENT CONTROL WATTLE

(not biodegradable) - for Perimeter Control, Slopes & Ditch Checks


98% effective GATOR GUARD wattles are a BETTER ALTERNATIVE to straw wattles and silt fence for most, but not all applications. (20 times less soil loss than straw wattles -6-inch Gator Guard vs 8-9-inch Straw)

NOT ON YOUR PLANS - Write in Gator Guard wattles on the SWPPP as an equal or better BMP, sign and date. (if in-doubt, check with your engineer, contract administrator and/or agency official first)

**PACKAGE INCLUDES:** One 25-foot wattle, 22 nails, 2 zip ties (UV resistant geotextile stuffed with recycled closed-cell foam.)

# **INSTALLATION** Standard or Extreme – Single or Double Apron

- 1. Prepare a smooth path or trench and install per drawings below, OR TRENCH IN.
- 2. Do not place wattles across rock site entrance. Limit Collection Area - Release water to a hard surface in several places.
- 3. Place wattle with tag downhill (tag at left end - looking uphill).
- Reposition Foam: **Standard** shake the squeezed end. **Extreme** shove foam in tight. 4.
- For sidewalk application, nail both aprons uphill per drawing. Fill to top of sidewalk. 5.
- Nail uphill apron every 3-feet (2-inches from edge of apron) using nails included. Nail 6. downhill splash apron every 6-feet, if used (for slopes and ditch checks).
- 7. Connect two wattles (per figure). Overlap aprons, pull sleeve tightly over second wattle, and nail through all aprons tight and smooth.
- Place 1-inch of dirt minimum on uphill apron and compact with your feet. 8.
- To cut a wattle, shake stuffing from desired cut location, insert two zip ties around wattle 9. tube about 6-inches apart and tighten. Cut fabric with a scissors.
- For high flow channels, use a series of wattles to catch sediment overflow. 10.



- 1. Repair cuts with zip ties – stuff anything in the hole for temporary fix – pick up foam.
- Inspect, clean out excess sediment and repair washouts after each runoff event. 2.
- Dispose of wattle properly if damaged, deteriorated or no longer needed. 3.

### **REMOVAL / RE-USE**

- 1. Pull up wattle by hand, remove dirt and nails for reuse, or THROW IT AWAY - it's OK.
- 2. Remove weeds and seeds before transport to another site.





# SPECIFICATIONS – STANDARD & EXTREME SEDIMENT CONTROL WATTLE



Standard foam pieces can escape if the fabric is ripped open, or deteriorated, creating foam litter – pick it up.

\*\*Note: Extreme - Wattle keeps nearly full height when driven over and has no foam litter if ripped open

140tc. Extreme - Wattle keeps hearly full height when driven over, and has no roam fitter if hipped open.		
Install Pins 5-in Galvanized Deck Nails Included	22 nails in each pack	22 nails in each pack
Alt. Install Pins 6-12 inch Landscape Staples	Purchase Locally	
Alt. Install Pins - Big Nails 40-D or larger	Purchase Locally	
Installation Pin Spacing	3-ft upstream apron, 6-ft splash apron	
11-inch Cable Ties (for cut-to-length & Repair)	2 included (near tag)	
Cover apron w/ dirt (compact w/ feet)	1-inch of dirt minimum	
Accidental cut repair	Secure cut with zip ties or replace	
Functional Life (expected)	5 years (excludes major damage)	
Soils Lab Testing	San Diego State University – Jan. 2008	
% Effective - LA Basin 10-yr storm Equiv.	98% effective for 3:1 slope	

Date: October, 2021 – The above properties are typical averages.

All test methods are ASTM or Industry Standards.